

# **Table of Contents**

General	Introduction	1
	Introduction	
	Local Building Codes	
	Tools Required	
	Additional Assistance	
Parts Gl	ossary	
	Hardware Components	2-4
	Straight Track	5
	Drops	6
	Bends	7-9
Installat	ion - Ceiling	
Please select	ceiling type and proceed to page 16	
	Installing into ACT Grid	10
	Installing into Traditional Cubicle Curtain Track	11
	Installing into Gypsum Board Ceilings	12
	Installing into Plywood Ceilings	13
	Installing into Concrete or Masonry Ceilings	14
	Installing into a Wall/Soffit	15
Installat	ion - Components	
	Parts Assembly	16
	Connecting the Track Connector	17
	Connecting the Hanger & Track Connector	18
	Connecting the End Cap & Curtain Stopper	19
	Connecting the Swivel End Wall Plate	20
	Installing a Loading Zone	21
	Installing Drops	24
	Installing ACT Conduit	25
	Installing Grid Blocking	26
Append	ix	
	Graphical Track Assembly	27
	Graphical Track Assembly with Drops	28
	Graphical Ceiling Installation	29
	Installation and Building Code for Concrete Anchors	31
Mainten	ance	39

### **General Introduction**

### Introduction

On The Right Track's worldwide patented cubicle curtain system includes a state-of-the-art track system that will give you years of ageless beauty and carefree enjoyment.

The following illustrated instructions have been provided to help you understand and take advantage of various scenarios and their appropriate installation techniques. Following these instructions along with good building practices will deliver the highest quality installation. Failure to follow these instructions also risks voiding the OTRT warranty.

### **Local Building Codes**

Please follow all building codes and good construction practices when installing the curtain track. In addition to local codes, be sure to follow the instructions in this guide. Failure to do so may void your OTRT warranty.

### Tools required

5/64" Phillips drill bit
Rubber mallet
Phillips screwdriver
Chop Saw with a non-ferrous aluminum blade or Hand Saw File
Laser Level
Measuring Tape
TE-CX 1/4" x 6" Hammer drill bit (for concrete anchors only)
HILTI 7/16" Drive Socket ( for concrete anchors only)

### **Additional Assistance**


For additional assistance, be sure to view our installation videos at: https://www.youtube.com/watch?v=njrXMbe6izM

Patent No.: https://ontherighttrack.com/patents


©2021 On the Right Track Systems Inc. All rights reserved.

On the Right Track®, The Grabber® and the material included herein, including text, graphics and the selection and arrangement thereof are the property of On the Right Track Systems, Inc. and are protected by copyright, trademark and other intellectual property laws. All other trademarks, product names and company names or logos cited herein are the property of their respective owners.


# **Hardware Components**




Part# OPTS-AN-C 1/4" x 2 5/8" Anchor for Concrete and Masonry



Part # OPTS-B03 Hard Ceiling Mounting Plate



Part # OPTS-C03-S Swivel End Wall Plate




Part # OPTS-E03 Hanger & Track Connector






Part # OPTS-F03M Hangar Track Connector




Part # OPTS-G03N Hanger

# **Hardware Components**


Part # OPTS-LZ Curtain Loading Zone 36"



Part # OPTS-P03
Ceiling Vertical Mount Plate for Drops




Part # OPTS-S03
Thumb Screw with Fastener



Part # OPTS-S102 5/32" x 8.2mm Screw





Part # OPTS-M03 Combo End Cap




Part # OPTS-Q03 Room Divider Wall Mount






Part #OPTS-S03-2 Fastener






Part # OPTS-S302 5/32" x 13mm Self Tap Screw


# **Hardware Components**




Part # OPTS-S602 5/32" x 16mm Screw




Part# OPTS-S602-CA 1/6 x 1-1/2 Self Tapping Screw for CA




Part# OPTS-S802-W 1/4 x 1 1/2" Anchor for Gypsum Board & Wood




Part # OPTS-S902-1 (5/32 x 1" screw)




Part # OPTS-T03 Retrofit Track Adapter




Part# OPTS-T03-W Track Adapter Washer




Part # OPTS-U02 Curtain Stopper




Part# OPTS-W03
Ceiling Blocking
(only if required by code)



Part# OPTS-W03-N Ceiling Blocking (for recessed ACT)




Part # OPG-005 The Grabber®




Part# OPTS-X03 ACT Conduit


# **Straight Track**




# Drops



### **Bends**





Part# OPTS- K1R03 90° Reversed 1 Ft Radius Track




Part# OPTS-K1R03-LZ 90° Reversed 1 Ft Radius Track w/LZ 8ft



Part# OPTS- K203 90° 2 Ft Radius Track



Part# OPTS- K2R03 90° Reversed 2 Ft Radius Track



Part# OPTS- K403 90° 4 Ft Radius Track



Part# OPTS- K403-10 4 Ft Radius Track 10ft (80% of semi-circle)



Part# OPTS- K5R03 90° Reversed 5 Ft Radius Track

### **Bends**



Part# OPTS- L103 135° 1 Ft Radius Track



Part# OPTS- L1R03 135° Reversed 1 Ft Radius Track



Part# OPTS- L203 135° 2 Ft Radius Track



Part# OPTS- L2R03 135° Reversed 2 Ft Track

# **Regular Vs Reversed Bends**

OPTS - K103
90° 1 FT RADIUS TRACK


BACK SIDE
OF THE
CURTAIN


FRONT SIDE
OF THE
CURTAIN

90° REVERSED 5 FT RADIUS TRACK

135° (45°) REVERSED 1 FT RADIUS TRACK

**OPTS - L1R03** 






# **Installing into ACT Grid**

#### **Directions:**

- 1. The Drop Ceiling Grid Mount is a three piece mount. Assemble prior to attaching to drop ceiling grid work.
- 2. Secure a Drop Ceiling Mount piece (part# OPTS-S03) to the ACT grid using the included screw (part# OPTS-S03-SCR).
- 3. If using drops, use 2 pieces of **OPTS-S902-1** screws into a Ceiling Vertical Hanger Mount Plate (**part# OPTS-P03**).

  If the drop is greater than 12", also attach a Support Bracket (**part# OPTS-J03-SB**) from the drop (**part# OPTS-J03**) to the ceiling.




- The ceiling mount should be 6" away from the wall and then installed every 24".
- If this installation is in California and you are using drops, the maximum drop distance allowed is 24".
- ONCE COMPLETE, PLEASE GO TO PAGE 16.

# Installing into Traditional Cubicle Curtain Track

# (With 1/2" opening at bottom)

#### **Directions:**

- 1. Insert the Track Adapter (part# OPTS-T03) into pre-installed traditional track.
- 2. Secure a Fastener (part# OPTS-S03-2) to the Track Adapter through a Washer (part# OPTS-T03-W) and Hanger (part# OPTS-G03N) using the middle hole.
- 3. If using drops, use 2 pieces of **OPTS-S602** screws into a Ceiling Vertical Hanger Mount Plate (**part# OPTS-P03**) and Track Adapter (**part# OPTS-T03**).




- The ceiling mount should be 6" away from the wall and the installed every 24".
- If this installation is in California, you will need to also install an **OPTS-S602-CA** screw through one of the open holes on the Track Adapter (**part# OPTS-T03**) and all the way through both the traditional track and ceiling above it.
- If this installation is in California and you are also using drops, the maximum dropdistance allowed is 24".
- ONCE COMPLETE, PLEASE GO TO PAGE 16.

# **Installing into Gypsum Board Ceilings**

#### **Directions:**

- 1. Please check local city and state regulations regarding the installation into gypsum board ceilings before proceeding.
- 2. Attach a Hard Ceiling Mount Plate (part# OPTS-B03) to the ceiling using 4 pieces of OPTS-S802-W anchors.
- If using drops, use 3 pieces of OPTS-S802-W anchors into a Ceiling Vertical
  Hanger Mount Plate (part# OPTS-P03).

  If the drop is greater than 12", also attach a Support Bracket (part# OPTS-J03-SB) from the
  drop (part# OPTS-J03) to the ceiling.




- The anchors should be installed using a very low torque setting on your drill or with an ordinary Phillips screwdriver. **DO NOT OVER-TORQUE SCREWS**.
- A laser level is very useful when laying out locations for the hard ceiling mount plates.
- The ceiling mount should be 6" away from the wall and then installed every 24".
- If this installation is in California and you are using drops, the maximum drop distance allowed is 24".
- ONCE COMPLETE, PLEASE GO TO PAGE 16.

# **Installing into Plywood Ceilings**

#### **Directions:**

- Attach a Hard Ceiling Mounting Plate (part# OPTS-B03) to the ceiling using 2 pieces of OPTS-S802-W anchors.
- If using drops, use 3 pieces of OPTS-S802-W anchors into a Ceiling Vertical
  Hanger Mount Plate (part# OPTS-P03).
   If the drop is greater than 12", also attach a Support Bracket (part#OPTS-J03-SB) from the drop
  (part# OPTS-J03) to the ceiling.




- The anchors should be installed using a very low torque setting on your drill or with an ordinary Phillips screwdriver. DO NOT OVER-TORQUE SCREWS.
- A laser level is very useful when laying out locations for the hard ceiling mount plates.
- The ceiling mount should be 6" away from the wall and then installed every 24".
- If this installation is based in California, the maximum drop distance allowed when installed into plywood substrate is 20".
- ONCE COMPLETE, PLEASE GO TO PAGE 16.

# Installing into Concrete/Masonry Ceilings

#### **Directions:**

- 1. Attach a Hard Ceiling Mounting Plate (part# OPTS-B03) to the ceiling using 2 pieces of OPTS-AN-C anchors.
  - a. In order to stay within code, please refer to the Appendix on page 31 for detailed anchor installlation instructions and building code information.
- 2. If using drops, use 1 piece of OPTS-AN-C anchor into a Ceiling Vertical Hanger Mount Plate (part# OPTS-P03).

If the drop is greater than 12", also attach a Support Bracket (part# OPTS- J03-SB) from the drop (part# OPTS-J03) to the ceiling.





- A laser level is very useful when laying out locations for the hard ceiling mount plates
- The ceiling mount should be 6" away from the wall and then installed every 24".
- In order to stay within code, please refer to the Appendix on page 29 for detailed anchor installation instructions and building code information.
- If this installation is in California and you are using drops, the maximum drop distance allowed is 24".
- ONCE COMPLETE, PLEASE GO TO PAGE 16.


# Installing into a Wall/Soffit


#### **Directions:**

- 1. Attach a Wall Mounting Plate (part# OPTS-Q03) to the wall using 2 pieces of OPTS-S802-W anchors.
- 2. After the Track and Hanger Connector (part# OPTS-E03) has been inserted into the back of the track, slide it on to the Wall Mounting Plate and secure it with an OPTS-S102 screw.










- The anchors should be installed using a very low torque setting on your drill or with an ordinary Phillips screwdriver. DO NOT OVER-TORQUE SCREWS.
- A laser level is very useful when laying out locations for the wall mount plates.
- The wall mount should be installed every 24".

# **Parts Assembly**


#### **Directions:**

1. Attach the Hanger (**part# OPTS-G03N**) to the appropriate ceiling mount piece (dependent on ceiling type) and secure.



**ACT Grid Mount** 







- Once all the Hangers have been installed, go back and insert the other ends into the Hanger & Track Connectors (part# OPTS-E03) installed on page 18. This is secured using an OPTS-S102 screw.
- The first hanger assembly (**OPTS-G03N**) should be 6" away from the wall and then installed every 24".

### **Connecting the Track Connector**

#### **Directions:**


- Join together two pieces of track by sliding the Track Connector (**part#OPTS- F03M**) into each adjoining end of track.
- Make sure the piece is all the way in and snug. You may need to use a rubber mallet to achieve this.
- Once the piece is in place, secure with 2 pieces of **OPTS-S102**.





#### Notes:


During the installation process, it may become necessary to cut the track in order to get a perfect fit. Be sure to take care in cutting the end of the track that does not join to another track.
 Manufactured/ finished ends of the track are ideal for joining with the Connector piece. Cut ends may be capped off at the end of the track by using an End Cap (part# OPTS-M03). Also make sure all connections are perfectly straight 180 degrees. Please see the below example for further clarification:



# **Connecting the Hanger & Track Connector**

#### Directions:

- 1. Make sure the track is right side up. This will be evident by noting a smooth rounded top and a lip at the bottom.
- 2. Place the end of the Hanger & Track Connector (**part# OPTS-E03**) into the groove on the back side of the track and turn clockwise 1/4 turn. This will lock the piece into place.
- 3. If you need to reposition, simply reverse the process.
- 4. The other end of this piece connects to the hanger (part# OPTS-G03N) that should be suspended from the ceiling (done earlier). This is secured using an OPTS-S102 screw.




#### Notes:

• The Hanger & Track Connector should only be turned in a clockwise direction.

# **Connecting the End Cap & Curtain Stopper**

#### **Directions:**


To connect an End Cap (part# OPTS-M03), simply slide into place and secure with a self-tapping screw (part# OPTS-S302) on the front.



Connecting to the Wall

#### **Directions:**


- 1. Use 2 pieces of **OPTS-S802-W** anchors to secure to the wall.
- 2. To connect a Curtain Stopper (**part# OPTS-U02**), simply place on top of the end cap and use the same S302 screw.



# **Connecting the Swivel End Wall Plate**

#### **Directions:**

- 1. To connect a Swivel End Wall Plate (**part# OPTS-C03-S**), simply slide into place and secure with a self-tapping screw (**part# OPTS-S302**) on the front.
- 2. Use 4 pieces of **OPTS-S802-W** anchors to secure to the wall.
- 3. To connect a Curtain Stopper (**part# OPTS-U02**), simply place on top of the end cap and use the same S302 screw




# **Installing a Loading Zone**


### Must be installed with every bed

#### **Directions:**

- 1. Install first Drop Ceiling Grid Mount piece (part# OPTS-S03) 2" away from the wall.
- 2. Make sure the Loading Zone (**part# OPTS-LZ**) is right side up. This will be evident by noting a smooth rounded top and a flat edge at the bottom.





3. Place the hanger and track connector (part# OPTS-E03) into the first groove on the back side of the Loading Zone track and turn clockwise 1/4 turn. Attach the other end to a hanger (part# OPST-G03N) and secure with an OPTS-S102 screw. Connect the hanger to the S03 piece from Step 1.



# **Installing a Loading Zone**


4. Fasten the Loading Zone (part# OPTS-LZ) to the wall with an End Cap (part# OPTS-M03), which is secured using two anchors (part# OPTS-S802-W).





# **Installing a Loading Zone**

5. Attach the other end of the Loading Zone to adjacent track using a track connector (**part#OPTS-F03M**) and two **OPTS-S102** screws.




#### Notes:

• Make sure that the Loading Zone is level when installed.

# **Installing Drops**

#### **Directions:**

- Insert an Extensible Tube (part# OPTS-J03) into the Ceiling Vertical Hanger Mount Plate (part# OPTS-P03). You may need a rubber mallet to completely insert the tube. This should be done before you attach the mount plate to the ceiling. Also be sure to insert the cut end into the plate (or the end that does not have a hole).
- Secure with an OPTS-S302 screw.
- 3. Attach a Hanger (part# OPTS-G03N) and secure with an OPTS-S03-2 fastener.
- If the drop is equal or greater than 12", also attach a support bracket (part# OPTS-J03-SB) from the drop (part# OPTS-J03) to the ceiling.




- Our Extensible Tubes are used to drop the rail to a specific height. These come in 6", 1', 2 and 4' sizes and may need to be cut to size in the field before installation.
- The Mount Plate is designed to taper so that once the tube has been completely inserted, it will
  not flex. For instructions on installing the Ceiling Vertical Hanger Mount Plate (part# OPTS-P03)
  into the ceiling, please refer to the appropriate ceiling page in this manual.
- The ceiling mount should be 6" away from the wall and then installed every 24".
- If this installation is in California and you are using drops, the maximum drop distance allowed is 20" when installed into plywood substrate, and 24" into other materials.

# **Installing ACT Conduit**


#### **Directions:**

- 1. Mark the areas where drops are required in an ACT ceiling.
- 2. Cut a hole in the tile large enough to insert an Extensible Tube (part# OPTS-J03).
- 3. Insert an ACT Conduit (part# OPTS-X03) into the dropped ceiling tile. The top clips of the piece should rest on top of the tile.
- 4. Insert an Extensible Tube (**part# OPTS-J03**) through the piece and continue with installation detailed on page 24.




# **Installing Grid Blocking**


#### **Directions:**




1. Insert OPTS-S03 male screw through the right clip opening of (part# OPTS-W03) and attach to ACT grid.



2. Attach left clip to ACT grid ensuring it locks with the right clip at the top and bottom.




3. Secure both clips with 12 GA hanger wire up to the ceiling above.




4. Attach a hanger (part# OPTS-G03N) and secure with a female OPTS-S03.


- The ceiling mount should be 6" away from the wall and then installed every 24".
- Only if required by code.


# **Graphical Track Assembly**






# **Graphical Track Assembly with Drops**







# **Graphical Ceiling Installation**



# **Track Assembly with Drops**



**Traditional Track With Drops** 



#### 3.3.5 KWIK HUS-EZ (KH-EZ) Carbon Steel Screw Anchor

3.3.5.1	Product Description
3.3.5.2	Material Specifications
3.3.5.3	Technical Data
3.3.5.4	Installation Instructions
3.3.5.5	Ordering Information



#### Listings/Approvals

ICC-ES (International Code Council) ESR-3027 (Cracked & Uncracked Concrete)

AC 106 ESR Pending (Grout filled concrete masonry)

City of Los Angeles Research Report No. 25897



#### **Independent Code Evaluation**

IBC® / IRC® 2009 (AC 193 / ACI 355.2) IBC® / IRC® 2006 (AC 193 / ACI 355.2) IBC® / IRC® 2003 (AC 193 / ACI 355.2)

### 3.3.5.1 Product Description

Hilti KWIK HUS-EZ (KH-EZ) anchors are comprised of a body with hex washer head. The anchor is manufactured from carbon steel and is heat treated. It has a minimum 0.0003 inch (8 µm) zinc coating in accordance with DIN EN ISO 4042. The KWIK HUS-EZ (KH-EZ) system is available in a variety of lengths with diameters of 1/4 inch, 3/8 inch, 1/2 inch, 5/8 inch and 3/4 inch (6.4mm, 9.5mm, 12.7mm, 15.9mm and 19.1mm). The hex head is larger than the diameter of the anchor and is formed with serrations on the underside. The anchor body is formed with threads running most of the length of the anchor body. The anchor is installed in a predrilled hole with a powered impact wrench or torque wrench. The anchor threads cut into the concrete on the sides of the hole and interlock with the base material during installation. Applicable base materials include normal-weight concrete, structural lightweight concrete lightweight concrete over metal deck, and grout filled concrete masonry.

#### **Guide Specifications**

Screw anchors shall be
KWIK HUS-EZ as supplied by
Hilti, Inc. Anchors shall be
manufactured from heat treated
carbon steel material, zinc plated
to a minimum thickness of 8µm.
Anchor head shall display name of
manufacturer, product name, diameter
and length. Anchors shall be installed
using a drill bit of same nominal
diameter as anchor.

#### **Product Features**

- Suitable for cracked and uncracked normal weight and lightweight concrete, and grout filled concrete masonry.
- Suitable for seismic and nonseismic loads.
- · Quick and easy to install.

- Length and diameter identification clearly stamped on head facilitates quality control and inspection after installation.
- Through fixture installation improves productivity and accurate installation.
- Thread design enables quality setting and exceptional load values in wide variety of base material strengths.
- · Anchor is fully removable
- Anchor size is same as drill bit size and uses standard diameter drill bits.
- Suitable for reduced edge distances and spacing.


# 3.3.5.2 Material Specifications

Hilti KWIK HUS-EZ anchors are manufactured from carbon steel. The anchors are bright zinc plated to a minimum thickness of 8µm.

# 3.3.5.3 Technical Data

The data contained in Tables 1-5 of this section have been evaluated in accordance with AC 193. For more detail, see ICC-ES ESR 3027.

Figure 1 — KWIK HUS-EZ anchor installation details





### KWIK HUS-EZ (KH-EZ) Carbon Steel Screw Anchor 3.3.5

Table 1 — KWIK HUS-EZ Specification Table 1,2,3

Charastariatia	Cumala al	Units				١	lominal A	Anchor D	iameter	(inches)				
Characteristic	Symbol	Units	1,	/4		3/8			1/2		5,	/8	3,	/4
Nominal Diameter	d <sub>a</sub>	in.	1,	/4		3/8			1/2		5,	/8	3,	/4
Drill Bit Diameter	d <sub>bit</sub>	in.	1,	1/4 3/8					1/2		5,	/8	3/4	
Baseplate Clearance Hole Diameter	d <sub>h</sub>	in.	3,	/8		1/2			5/8		3,	/4	7,	/8
Installation Torque4	T <sub>inst</sub>	ft-lbf	1	8		40			45		8	5	1	15
Impact Wrench Torque Rating <sup>3</sup>	T <sub>impact</sub>	ft-lbf	114	137	114	45	50	137	4	50	45	50	4	50
Nominal Embedment depth	h <sub>nom</sub>	in.	1-5/8	2-1/2	1-5/8	2-1/2	3-1/4	2-1/4	3	4-1/4	3-1/4	5	4	6-1/4
Effective Embedment Depth	h <sub>ef</sub>	in.	1.18	1.92	1.11	1.86	2.50	1.50	2.16	3.22	2.39	3.88	2.92	4.84
Minimum Hole Depth	$h_{\scriptscriptstyle{\circ}}$	in.	2	2-7/8	1-7/8	2-3/4	3-1/2	2-5/8	3-3/8	4-5/8	3-5/8	5-3/8	4-3/8	6-5/8
Critical Edge Distance <sup>2</sup>	C <sub>ac</sub>	in.	2.00	2.78	2.10	2.92	3.75	2.75	3.75	5.25	3.63	5.81	4.41	7.28
Minimum Spacing at critical edge Distance	S <sub>min,cac</sub>	in.	1.	50		2.25				3				4
Minimum Edge Distance <sup>2</sup>	C <sub>min</sub>	in.			1.50						1.75			
Minimum Spacing at Minimum Edge Distance	S <sub>min</sub>	in.					3						4	4
Minimum ConcreteThickness	h <sub>min</sub>	in.	3.25	4.125	3.25	4	4.875	4.5	4.75	6.75	5	7	6	8.125
Wrench socket size	-	in.	7/16 9/16 3/4 15/16						1-	1/8				
Head height	-	in.	0.24 0.35 0.49 0.57						0.	70				
Effective tensile stress area	A <sub>se</sub>	in.²	0.045 0.086 0.161 0.268						0.3	392				
Minimum specified ultimate strength	$f_{ m uta}$	psi	134	,000	106,225	120	,300		112,540		90,	180	81,	600

For SI: 1 inch = 25.4 mm, 1 ft-lbf = 1.356 N-m, 1 psi = 6.89 Pa, 1 in<sup>2</sup> =  $645 \text{ mm}^2$ , 1 lb/in = 0.175 N/mm

<sup>1</sup> The data presented in this table is to be used in conjunction with the design criteria of ACI 318 Appendix D.

<sup>2</sup> For installations through the soffit of steel deck into concrete (see Figure 2) anchors installed in the lower flute may be installed with a maximum 1 inch offset in either direction from the center of the flute.

<sup>3</sup> Because of variability in measurement procedures, the published torque of an impact tool may not correlate properly with the above setting torques. Over-torquing can damage the anchor and/or reduce its holding capacity.

<sup>4</sup>  $T_{\text{inst,max}}$  applies to installations using a calibrated torque wrench.



#### 3.3.5 KWIK HUS-EZ (KH-EZ) Carbon Steel Screw Anchor

#### Table 2 — KWIK HUS EZ (KH EZ) Tension Strength Design Information<sup>1,2,3,4,5</sup>

Charastaristis	Cumple of	Units					Nominal	Anchor	Diamete	er(inches	s)				
Characteristic	Symbol	Units	1,	/4		3/8			1/2		5,	/8	3	/4	
Anchor Category 1,2 or 3									1	3 4-1/4 3-1/4 5 4  1120 24210 3201  1.16 3.22 2.39 3.88 2.92   1.67 5.25 3.63 5.82 4.81   27					
Nominal Embedment Depth	h <sub>nom</sub>	in.	1-5/8	2-1/2	1-5/8	2-1/2	3-1/4	2-1/4	3	4-1/4	3-1/4	5	4	6-1/4	
			Steel St	trength i	n Tensi	on (ACI	318 D 5	.1) <sup>6</sup>							
Tension Resistance of Steel	N <sub>sa</sub>	lb.	60	70	9125	10	335		18120		242	210	32	013	
Reduction Factor for Steel Strength <sup>2</sup>	Ф <sub>sa</sub>	-						0.	65						
		Concr	ete Brea	kout St	rength i	n Tensio	on (ACI	318 D.5.	2)						
Effective Embedment Depth	h <sub>ef</sub>	in.	1.18	1.92	1.11	1.86	2.50	1.52	2.16	3.22	2.39	3.88	2.92	4.84	
Critical Edge Distance	C <sub>ac</sub>	in.	2.00	2.78	2.10	2.92	3.74	2.75	3.67	5.25	3.63	5.82	4.81	7.28	
Effectiveness Factor — Uncracked Concrete	k <sub>uncr</sub>	-			24						27				
Effectiveness Factor — Cracked Concrete	k <sub>cr</sub>	-						1	7						
Modification factor for cracked and uncracked concrete <sup>5</sup>	$\Psi_{c,N}$	-		1.0											
Reduction Factor for Concrete Breakout Strength <sup>2</sup>	Фсь	-					(	).65 (Coi	ndition E	3)					
	Pullout	Streng	th in Te	nsion (N	Ion Seis	mic Ap	plication	ns) (ACI3	318 D.5.	3)					
Characteristic pullout strength, uncracked concrete (2,500psi)	N <sub>p,uncr</sub>	lb.	1305⁴	23484					N	/A					
Characteristic pullout strength, cracked concrete (2500 psi)	N <sub>p,cr</sub>	lb.	6324	1166⁴	7284					N/A					
Reduction factor for pullout strength <sup>2</sup>	Фр	-					(	).65 (Coi	ndition E	3)					
	Pullo	ut Stre	ngth in	Tension	(Seismi	c Applic	cations)	(ACI 318	3 D.5.3)						
Characteristic Pullout Strength, Seismic (2,500 psi)	N <sub>eq</sub>	lb.	632 <sup>4</sup> 1166 <sup>4</sup> 728 <sup>4</sup> N/A												
Reduction Factor for Pullout Strength <sup>2</sup> (2,500 psi)	Φ <sub>eq</sub>	-	0.65 (Condition B)												
		Axial Stiffness in Service Load Range													
Uncracked Concrete	$\beta_{\text{uncr}}$	lb/in.		760,000											
Cracked Concrete	$\beta_{cr}$	10/111.						293	,000						

For SI: 1 inch = 25.4 mm, 1 ft-lbf = 1.356 N-m, 1 psi = 6.89 Pa, 1 in<sup>2</sup> = 645 mm<sup>2</sup>, 1 lb/in = 0.175 N/mm

- 1 The data in this table is intended for use with the design provisions of ACI 318 Appendix D; for anchors resisting seismic load combinations the additional requirements of D.3.3 shall apply.
- 2 Values of Φ in this table apply when the load combinations for ACI 318 Section 9.2, IBC Section 1605.2.1 are used and the requirements of ACI 318 D.4.4 for Condition B are met. If the load combinations of ACI 318 Appendix C are used, the appropriate value of Φ must be used. For situations where reinforcement meets the requirements of Condition A, ACI 318 Section D.4.4 provides the appropriate φ factor.
- 3 N/A denotes that pullout resistance does not govern and does not need to be considered.
- 4 The characteristic pullout resistance for concrete compressive strengths greater than 2500 psi may be increased by multiplying the value in the table by  $(f')/(2,500)^{1/2}$  for psi or  $(f')/(17.2)^{1/2}$  for MPa.
- 5 For sand-lightweight concrete, multiply concrete capacity values and pullout values by 0.60.



#### KWIK HUS-EZ (KH-EZ) Carbon Steel Screw Anchor 3.3.5

Table 3 — KWIK HUS EZ (KH EZ) Shear Strength Design Information 1,2,3,4,5

Ole a manufaction	0	I Indian					Nominal	Anchor l	Diamete	r (inches)	)			
Characteristic	Symbol	Units	1,	/4		3/8			1/2		5,	/8	3,	/4
Anchor Category	1,2 or 3			1										
Embedment Depth	h <sub>nom</sub>	in.	1-5/8	2-1/2	1-5/8	2-1/2	3-1/4	2-1/4	3	4-1/4	3-1/4	5	4	6-1/4
			Stee	Streng	th in She	ear (ACI	318 D 6	.1) <sup>4, 5</sup>		•			•	
Shear Resistance of Steel — Static	V <sub>sa</sub>	lb.	15	i48	4057	51	85		9245		112	221	160	662
Shear Resistance of Steel — Seismic	V <sub>eq</sub>	lb.	13	193	2524	31	11		5547		67	33	11!	556
Reduction Factor for Steel Strength	Φ <sub>sa</sub>	-		0.60										
		Co	ncrete l	Breakou	t Streng	th in She	ear (ACI	318 D.6	.2)					
Nominal Diameter	d <sub>a</sub>	in.	0.2	250		0.375			0.500		0.6	25	0.7	750
Load Bearing Length of Anchor	$\ell_{ m e}$	in.	1.18	1.92	1.11	1.86	2.50	1.52	2.16	3.22	2.39	3.88	2.92	4.84
Reduction Factor for Concrete Breakout Strength	Фсь	-						0.	70					
		С	oncrete	ncrete Pryout Strength in Shear (ACI 318 D.6.3)										
Coefficient for Pryout Strength	k <sub>cp</sub>			1.0 2.0 1.0 2.0 1.0 2.0							2.0			
Reduction Factor for Pryout Strength	Ф <sub>ср</sub>	-						0.	70					

For SI: 1 inch = 25.4 mm, 1 ft-lbf = 1.356 N-m, 1 psi = 6.89 Pa, 1 in<sup>2</sup> =  $645 \text{ mm}^2$ , 1 lb/in = 0.175 N/mm

- 1 The data in this table is intended for use with the design provisions of ACI 318 Appendix D
- 2 Values of Φ in this table apply when the load combinations for ACI 318 Section 9.2, IBC Section 1605.2.1 are used and the requirements of ACI 318 D.4.4 for Condition B are met. If the load combinations of ACI 318 Appendix C are used, the appropriate value of Φ must be used. For situations where reinforcement meets the requirements of Condition A, ACI 318 D.4.4 provides the appropriate Φ factor.
- 3 Reported values for steel strength in shear are based on test results per ACI 355.2, Section 9.4 and must be used for design in lieu of calculated results using equation D-20 of ACI 318.
- 4 The KWIK HUS-EZ (KH-EZ) is considered a brittle steel element as defined by ACI 318 D.1.
- 5 For sand-lightweight concrete, multiply concrete breakout and concrete pryout values by 0.60.




#### 3.3.5 KWIK HUS-EZ (KH-EZ) Carbon Steel Screw Anchor

Table 4 – KWIK HUS-EZ (KH-EZ) Tension and Shear Design Data for Installation in the Underside of Concrete-Filled Profile Steel Deck Assemblies<sup>1,2,3,4,5</sup>

			Lower Flute Upper Flute															
Characteristic	Symbol	Units	Anchor Diameter															
			1,	/4		3/8			1/2		5,	/8	3/4	1,	/4	3,	/8	1/2
Embedment	h <sub>nom</sub>	in.	1-5/8	2-1/2	1-5/8	2-1/2	3-1/4	2-1/4	3	4-1/4	3-1/4	5	4	1-5/8	2-1/2	1-5/8	2-1/2	2-1/4
Minimum Hole Depth	h <sub>hole</sub>	in.	2	2-7/8	1-7/8	2-3/4	3-1/2	2-5/8	3-3/8	4-5/8	3-5/8	5-3/8	4-3/8	2	2-7/8	1-7/8	2-7/8	2-5/8
Effective Embedment Depth	h <sub>ef</sub>	in.	1.18	1.92	1.11	1.86	2.50	1.52	2.16	3.22	2.39	3.88	2.92	1.18	1.92	1.11	1.86	1.52
Pullout Resistance, (uncracked concrete)	N <sub>p,deck,uncr</sub>	lb.	1210	1875	1285	2240	3920	1305	3060	5360	4180	9495	4180	1490	1960	1015	2920	1395
Pullout Resistance (cracked concrete and seismic loads)	$N_{ m p,deck,cr}$	lb.	860	1330	1120	1965	3430	925	2170	3795	3070	7385	2630	1055	1390	885	2560	985
Steel Strength in Shear	V <sub>sa,deck</sub>	lb.	1205	2210	1670	1511	3605	1605	2922	3590	3470	4190	3762	1205	3265	3935	6090	7850
Steel Strength in Shear, Seismic	V <sub>sa,deck,eq</sub>	lb.	1080	1988	935	905	2163	963	1750	2154	2082	2514	2609	1080	2937	2203	3650	4710

- 1 Installation must comply with Figure 2.
- 2 The values in this table are derived in accordance with ACI 318 Appendix D, Section D.5.3.2.
- 3 The values for  $\phi_p$  in tension can be found in Table 2 of this report and the values for  $\phi_{sa}$  in shear can be found in Table 3.
- 4 For installations through the soffit of steel deck into concrete (see Figure 2) anchors installed in the lower flute shall be installed with a maximum 1 inch offset in either direction from the centerline of the flute.
- 5 The characteristic pullout resistance for concrete compressive strengths greater than 3,000 psi may be increased by multiplying the value in the table by  $(f'_{c}/3,000)^{1/2}$  for psi or  $(f'_{c}/20.7)^{1/2}$  for MPa.

Figure 2 - Installation of KWIK HUS-EZ (KH-EZ) in Soffit of Concrete Over Steel Deck Floor and Roof Assemblies



<sup>1</sup> Anchors may be placed in the upper or lower flute of the steel deck profile provided the minimum concrete cover above the drilled hole is satisfied. Anchors in the lower flute may be installed with a maximum 1-inch offset in either direction from the center of the flute. The offset distance may be increased proportionally for profiles with lower flute widths greater than those shown provided the minimum lower flute edge distance is also satisfied.



### KWIK HUS-EZ (KH-EZ) Carbon Steel Screw Anchor 3.3.5

Table 5 - KWIK HUS-EZ (KH-EZ) Allowable Stress Design Values for Illustrative Purposes 1,2,3,4,5,6,7,8,9,12

Nominal Anchor Diameter [in.]	Embedment Depth, h <sub>nom</sub> [in.]	Effective Embedment Depth, h <sub>ef</sub> [in.]	Allowable Tension Load <sup>10</sup> [lbs]	Allowable Shear Load <sup>11</sup> [lbs]
1 //	1 5/8	1.18	589	645
1/4	2-1/2	1.92	1060	645
	1-5/8	1.11	633	682
3/8	2-1/2	1.86	1374	1480
	3-1/4	2.50	2141	2160
	2-1/4	1.52	1142	1230
1/2	3	2.16	1934	2083
	4-1/4	3.22	3521	3852
F /O	3-1/4	2.39	2252	2425
5/8	5	3.88	4657	4675
0.74	4	2.92	3041	6549
3/4	6-1/4	4.84	6489	6943

For SI: 1 inch = 25.4 mm, 1 lbf = 4.45 N.

- 1 Single anchor with static tension or shear load only.
- 2 Concrete determined to remain uncracked for the life of the anchorage.
- 3 Load combinations are taken from ACI 318 Section 9.2 (no seismic loading).
- 4 40% dead load and 60% live load, controlling load combination 1.2D + 1.6L.
- 5 Calculation of weighted average for conversion factor  $\alpha = 1.2(0.4) + 1.6(0.6) = 1.44$ .
- 6 f' = 2,500 psi (normal weight concrete).
- 7  $c_{a1} = c_{a2} \ge c_{ac}$ , see Table 1.
- 8  $h \ge h_{min}$ , see Table 1.
- 9 Values are for Condition B where supplementary reinforcement in accordance with ACI 318 D.4.4 is not provided.
- 10 Allowable Tension Load = factored Load (Lessor of  $N_{_{D}}$  or Concrete Breakout from Table 2) ÷ 1.44
- 11 Allowable Shear Load = factored Load (Lessor of  $V_{sa}$  or Concrete Pryout from Table 3)  $\div$  1.44
- 12 Values are for single anchors installed without influence of base material edge distance or adjacent anchors.



#### 3.3.5 KWIK HUS-EZ (KH-EZ) Carbon Steel Screw Anchor

#### Table 6 - Allowable Tension Loads for KWIK HUS-EZ Installed in Grout-Filled Masonry Walls (lb)<sup>1,2,7,8</sup>

Anchor				Spacing			Edge Distance	
Diameter (inches)	Embedment (inches) <sup>3</sup>	Loads @ C <sub>cr</sub> and S <sub>cr</sub>	Critical - S <sub>cr</sub> (inches) <sup>4</sup>	Minimum - S <sub>min</sub> (inches) <sup>4</sup>	Load Reduction Factor at S <sub>min</sub> <sup>6</sup>	Critical - C <sub>cr</sub> (inches) <sup>5</sup>	Minimum C <sub>min</sub> (inches) <sup>5</sup>	Load Reduction Factor <sup>6</sup>
1 //	1 5/8	530	4	2	0.70	1	4	1.00
1/4	2 1/2	910	4	4	1.00	4	4	1.00
	1 5/8	535	4	2	0.70			
3/8	2 1/2	895	6	4	0.80	4	4	1.00
	3 1/4	1210	0	4	0.80			
	2 1/4	710	4	2				
1/2	3	1110	8	4	0.60	4	4	1.00
	4 1/4	1515	8	4				
F /0	3 1/4	1155	10	4	0.00	10	4	1.00
5/8	5	1735	10	4	0.60	10	4	1.00
2/4	4	1680	10	4	0.60	10	4	1.00
3/4	6 1/4	2035	12	4	0.60	12	4	1.00

#### Table 7 - Allowable Shear Loads for KWIK HUS-EZ Installed in Grout-Filled Masonry Walls (lb)1.2.7.8

				Spacing			Edg	ge Distance		
Anchor	Embedment	Load at C <sub>cr</sub>			Load	Critical -	Minimum -	Load Reduction Factor at C <sub>min</sub>		
Diameter (inches)			Critical - S <sub>cr</sub> (inches) <sup>4</sup>	Minimum - S <sub>min</sub> (inches) <sup>4</sup>	Reduction Factor at S <sub>min</sub> 6	C <sub>cr</sub> (inches)⁵	C <sub>min</sub> (inches) <sup>5</sup>	Load Direction Perpendicular to Edge	Load Direction Parallel to Edge	
1/4	1 5/8	675	4	4	1.00	4	4	1.00	1.00	
1/4	2 1/2	840	4	4	1.00	4	4	1.00	1.00	
	1 5/8	1140						0.61	1.00	
3/8	2 1/2	1165	6	4	0.94	6	4	0.70	1.00	
	3 1/4	1190						0.70	1.00	
	2 1/4	1845						0.50	1.00	
1/2	3	2055	8	4	0.88	8	4	0.45	0.94	
	4 1/4	2745						0.40	0.89	
E /0	3 1/4	3040	10	4	0.36	10	4	0.36	0.82	
5/8	5	3485	] 10	4	0.36	10	4	0.34	0.92	
2/4	4	3040	10	4	0.36	12	4	0.36	0.82	
3/4	6 1/4	3485	] 10	4	0.30	12	4	0.34	0.92	

- 1 All values are for anchors installed in fully grouted masonry with minimum masonry prism strength of 1500psi. Concrete masonry units shall be light-weight or normal-weight.
- 2 Anchors may not be installed within one inch in any direction of a vertical joint.
- $3\,$  Embedment depth is measured from the outside face of the concrete masonry embedment.
- 4 S<sub>cr</sub> is anchor spacing where full load values in the Table may be used. S<sub>min</sub> is the minimum anchor spacing for which values are available and installation is recommended. Spacing is measured from the center of one anchor to the center of an adjacent anchor.
- 5  $C_{cr}$  is the edge distance where full load values in the table may be used.  $C_{min}$  is the minimum edge distance for which values are available and installation is recommended. Edge distance is measured from the center of the anchor to the closest edge.
- 6 Load reduction factors are multiplicative, both spacing and edge distance load reduction factors must be considered.
  - Load values for anchors installed at less than  $C_{cr}$  or  $S_{cr}$  must be multiplied by the appropriate load reduction factor based on actual edge distance (C) or spacing (S).
- 7 Linear interpolation of load values between minimum spacing (S<sub>min</sub>) and critical spacing (S<sub>cr</sub>) and between minimum edge distance (C<sub>min</sub>) and critical edge distance (C<sub>min</sub>) is permitted
- critical edge distance ( $C_{cr}$ ) is permitted. 8 For combined loading: For 1/4" diameter  $\frac{T_{applied}}{T_{allowable}} + \frac{V_{applied}}{V_{allowable}} \le 1$  For 3/8" 3/4" diameter  $\left(\frac{T_{applied}}{T_{allowable}}\right)^{5/3} + \left(\frac{V_{applied}}{V_{allowable}}\right)^{5/3} \le 1$



### KWIK HUS-EZ (KH-EZ) Carbon Steel Screw Anchor 3.3.5

Table 8 - KWIK HUS-EZ Allowable Loads Installed In Top of Grout-Filled Concrete Masonry Construction (Ib)

Anchor	Minimum	Minimum	Minimum	Minimum		Sh	ear
Diameter (inches)	Embedment Depth (inches) <sup>2</sup>		Spacing (inches)	End Distance (inches)	Tension	Perpendicular to Edge of Masonry Wall	Parallel to Edge of Masonry Wall
1/2	4 1/4	1 3/4	8	4	680	305	1110
5/8	5	1 3/4	10	5	1310	305	1165


- 1 All values are for anchors installed in fully grouted masonry with minimum masonry prism strength of 1500psi. Concrete masonry units shall be light-weight or normal-weight.
- 2 Embedment depth is measured from the top of the masonry construction.

$$3 \text{ For combined loading:} \qquad \text{For 1/4" diameter -} \qquad \frac{T_{\text{applied}}}{T_{\text{allowable}}} \ + \ \frac{V_{\text{applied}}}{V_{\text{allowable}}} \ \leq \ 1 \qquad \text{For 3/8" - 3/4" diameter -} \ \left(\frac{T_{\text{applied}}}{T_{\text{allowable}}}\right)^{5/3} + \left(\frac{V_{\text{applied}}}{V_{\text{allowable}}}\right)^{5/3} \leq \ 1$$


#### 3.3.5.4 Installation Instructions

Drill holes in base material using carbide-tipped masonry drill bits complying with ANSI B212.15-1994. The nominal drill bit diameter must be equal to that of the anchor. The minimum drilled hole depth is given in Table 1. Prior to installation, dust and debris must be removed from the drilled hole using a hand pump, compressed air or a vacuum. The anchor must be installed into the predrilled hole using a powered impact wrench or installed with a torque wrench until the proper nominal embedment depth is obtained. The impact wrench


torque, T<sub>impact</sub> and installation torque, T<sub>inst</sub> for the manual torque wrench must be in accordance with Table 1. The KWIK HUS-EZ (KH-EZ) may be loosened by a maximum of one turn and reinstalled with a socket wrench or powered impact wrench to facilitate fixture attachment or realignment. For member thickness and edge distance restrictions for installations into the soffit of concrete on steel deck assemblies, see Figure 2.




Drill hole in base material using proper diameter drill bit.



Clean drilled hole to remove debris.



Fasten anchor tightly against fastened part.



Install anchor using proper impact tool or torque wrench.

# Maintenance

# The Only Track Maintenance You Will Ever Need



### Step 1:

Bend the end of a micro-fiber high-duster head at a 90 degree angle.

### Step 2:

Spray the inside of curve of the high-duster head with "Pledge Revitalizing Oil."



### Step 3:

Run the high-duster along the top of the rail to clean and maintain "*Quiet Glide*."